




Model A56D Microphone Drum Mount User Guide

GENERAL


The Shure A56D mounts microphones on a drum or cymbal. It fits stand adapters with a $\frac{5}{8}$ -in., 27-thread. An L-adapt-er extension curves at a 90° angle for optimum microphone placement.

The clamp fits drum rims measuring from $\frac{1}{2}$ -in. (12.7 mm) to $2\frac{1}{4}$ -in. (57.2 mm) in height, or on cymbal stands measuring from $\frac{3}{8}$ -in. (9.5 mm) to $1\frac{1}{8}$ -in. (28.6 mm) in diameter.

DRUM RIM MOUNTING




CYMBAL STAND MOUNTING



NOTE: To minimize potential noise or damage, position the microphone outside the drummer's range of stick movement and cymbal movement.

REPLACEMENT PARTS



Clamp Assembly RPM618



Jaw 32A866



L-Adapter Extension 90A4646



5/8"-27 Lock Nut (Large) 31A1857



5/8"-27 Lock Nut (Small) 31B1770



SHURE Incorporated Web Address: <http://www.shure.com>
5800 W. Touhy Avenue, Niles, IL 60714-4608, U.S.A.
Phone: 800-257-4873 Fax: 847-866-2279
In Europe, Phone: 49-7131-72140 Fax: 49-7131-721414
In Asia, Phone: 852-2893-4290 Fax: 852-2893-4055
Elsewhere, Phone: 847-866-2200 Fax: 847-866-2585